# No Sound

No sound coming out of Promethean boards?

Check the side of the board if the light is red press the button until it turns green.

Other problems

Check the volume isn't on mute by clicking on the sound icon on the task bar.